Q1C
User Manual

INTRODUCTION

Thank you for purchasing this Micromax mobile phone. To obtain the best performance of your phone, please read this user manual carefully.

Table of Contents

1 Safety 4

1.1 Safety Precautions4

2 Introduction 6

2.1 Phone and Accessories6
2.2 Your Phone6
2.3 Description of Display Contents7
2.4 About UIM Card and the Battery7
2.5 To switch ON and OFF7

3 Phonebook 8

3.1 To Add a Contact8
3.2 To Search a Contact8
3.3 Caller groups8
3.4 To Copy all8
3.5 To Delete a Contact8
3.6 Speed Dial8
3.7 Memory Status8
3.8 Owner Number9

4 Call Logs 9

4.1 Missed Calls/Dialed Calls/Received Calls9
4.2 Delete Call Logs9

5 Messages 9

5.1 Write SMS9
5.2 SMS Inbox9
5.3 SMS Drafts9
5.4 SMS Outbox9
5.5 SMS Settings10
5.6 Delete all SMS10
5.7 Voicemail Server10

6 Settings 10

6.1 Customized Phone & Call Settings10
6.2 Profile Setup10
6.3 Security Settings11

7 FM Radio 11

7.1 Fm Radio11

8 Music Player 12

8.1 Music Player12

9 File Manager 12

9.1 File Manager12
9.2 Memory Card12

9.3 Memory Status12
10 Alarm 12
10.1 Alarm12
11 Games 12
12 Organizer 13
13 Maintenance 13
14 Taking Care of your Device 13
15 After Services 13

1 Safety

1.1 Safety Precautions

Please read through the following briefings carefully, and act in accordance with these rules, so as to prevent causing any danger or violating any law.

Safe driving

1) Do not use the phone while driving. When you have to use the phone, please use the personal hands-free kit.

2) Please put the phone safely in the phone stand. Do not put it onto any passenger seat or any place from which it may fall down in case of vehicular collision or emergency braking.

Turn off during a flight: Flight is influenced by interference caused by the phone. It is illegal to use a phone on the airplane. Please turn off your phone during a flight.

Turn off the phone when within an area where blasting takes place: Be sure to strictly observe the related laws and statutes by turning off the phone when you are within, or in the vicinity of, an area where blasting takes place.

Turn off the phone when any dangerous goods are in vicinity: Please turn off your phone when you are close to a gas station or in the vicinity of any place where fuel and chemical preparations, or any other dangerous goods are stored.

In hospital: Please obey the related rules or bylaws of the hospital when using your phone in a hospital. Be sure to turn off your phone when near any medical equipment. Your use of any wireless transmission equipment, inclusive of the phone, will interfere with any medical equipment that is not protected fully, and other electronic equipment items, too. Should you have any question in this regard, please consult a related physician or medical equipment supplier.

Interference: Each and every phone's performance may be affected due to radio interference.

Professional service: The phone must be installed or repaired by no other personnel than professionals. You are likely to suffer a huge risk when you install or repair this phone by yourself, which also goes against the warranty rules.

Fittings and battery: You shall use the fittings and battery acknowledged by the phone manufacturer only. Using unauthorized accessories may tamper the warranty of the device.

Emergency call: You may enter a telephone number (112, etc.) to ask for emergency help after making sure that the phone has been turned on and is in the service status. Press the Send Key to call out.

Disclaimer: Micromax will not bear any responsibility for any incompliance with the above mentioned guidelines or improper usage of the mobile phone. Micromax keeps the right to make modifications to any of the content here in this user guide without public announcement in advance. The content of this manual may vary from the actual content displayed in the mobile phone. In such case, the latter shall govern.

2 Introduction

2.1 Phone and Accessories

Open the packing box of the phone and check for its contents which should be as follows:

1.Transceiver
2.Standard Charger
3.Standard Battery
4.Hands-free Kit
5.USB Cable
6.Service Guide
7.Warranty Card

2.2 Your Phone

2.3 Description of Display Contents

The table below lists the icons that may appear on the status bar according to the current priority of the phone.

Icons	Description
	Signal Indicator; More bars indicates stronger signal
	New message icon
	Message memory full icon
	Roaming icon (R-UIM card of overseas)
	Normal mode
	Meeting mode
	Outdoor mode
	Silent mode
	FM Radio icon
	Alarm icon
	Call firewall icon
	Message firewall icon
	Call firewall and Message firewall
	Keypad lock icon
	Phone locked icon
	Battery Level Indicator

2.4 About UIM Card and the Battery

Please store the cards out of childrens' reach.
The card and the contacts are vulnerable to damage due to scratching or bending. Therefore, be careful when using, inserting or removing the cards.
Be sure to switch OFF the phone before you insert or remove the battery or the card, otherwise, the phone may be damaged.

Insert the plug of the charger into the interface of the phone, and insert the charger into the power socket carefully. The battery icon will blink.
We suggest you recharge the battery when the power is used up so as to increase the life of the battery.

2.5 To switch ON and OFF

To switch ON: Long press **End key** when the phone is in the OFF mode.
If the phone lock has been activated, you need to enter the 4-digit password to unlock. (The preset unlock code is 0000.)
If the UIM card has been inserted in the phone, and the related PIN code protection is activated, you need to enter the 4-8 digit password to unlock.
Warning: If you enter three wrong PIN codes in a row, the UIM card will be locked and you need to enter the PUK code to unlock. Both the PIN code and PUK code are provided by the network operator.

To switch OFF: In the standby mode, long press **End key**.

3 Phonebook

You can store names and phone numbers in the memory of the phone or UIM card.

Menu > Phonebook

3.1 To Add a Contact

In idle, enter phone numbers.
Menu > Phonebook > Add new contact> Select the location for saving
You can edit the name & number.

3.2 To Search a Contact

Menu > Phonebook > Search a contact
Allows you to search a contact stored in your phonebook.

3.3 Caller groups

Menu > Phonebook > Caller Groups
Select a category from the group you wish to add a contact under- Family, Friends, VIP, Business & others

3.4 To Copy all

In the contact list of the Phonebook, select the name card to be copied

Tip: "Copy" means copying to other storage location. You can copy the entry stored in the UIM card to the phone memory and vice versa

You can copy all entries from UIM card to Phone and vice versa:
Menu > Phonebook > Copy All > From UIM to Phone to UIM.

3.5 To Delete a Contact

Menu > Phonebook > Delete>

In the idle screen press the **right soft key** to view names. In Contacts list, select the entry you want to delete: **Options > Delete**

3.6 Speed Dial

Menu>Phonebook>Speed dial
Allows you to mark a contact as a speed dial number.

3.7 Memory Status

Menu>Phonebook>Memory Status

You can view the used & available memory status in the phonebook.

3.8 Owner Number

Menu>Phonebook>Owner Number
Allows you to edit the name and number present under the 'owner number' section.

4 Call Logs

4.1 Missed Calls/Dialed Calls/Received Calls

Menu>Call center> Call history
When view the call logs. You may select from option:

Save To Phone book: To save the number to the Phonebook
Add to Blacklist: Add the number to the blacklist to avoid any future calls from this number.
Send Message: Send a message from your number to another number.

4.2 Delete Call Logs

Menu > Call logs> Call history> Delete call logs
You may select to delete **Missed**, **Dialed, Received** or **All** calls.

5 Messages

5.1 Write SMS

To write messages:
Menu > Messages > Write Message
Allows you to compose messages that you wish to send to other people on your contact list.

5.2 SMS Inbox

Menu > Messages > Inbox
All the messages received in your phone are stored under this 'Inbox' folder.

5.3 SMS Drafts

Menu > Messages > SMS Drafts
Messages composed by you that you do not wish to send out immediately can be saved under 'Drafts'.

5.4 SMS Outbox

Menu>Messages>Outbox
SMS messages from your phone that have been sent but fail to get delivered are

stored under 'Outbox'.

5.5 SMS Settings

Menu > Messages > SMS Settings
Priority Set: Set a priority for the messages.
Storage: Select preferred storage.
Save sent message: Choose the option for sent messages.
Memory Status: Check the message memory status.

5.6 Delete all SMS

Menu > Messages > Delete all SMS
Allows you to delete all the SMS.

5.7 Voicemail Server

Menu > Messages > Voicemail server
Set the voice mail numbers. When connecting by CDMA network, you can call and listen to the voice mail.
Note: This feature is network dependant

6 Settings

6.1 Customized Phone & Call Settings

Functions	Description
Set Time format	**Menu > Settings > Phone settings > Time format**
Auto Keypad Lock	**Menu > Settings > Phone settings > Auto keypad lock** Press the unlock tab to lock/unlock the phone.
Memory card format	**Menu > Settings > Phone settings > Memory card format**
USB function	**Menu > Settings Call settings > USB function**
Answer mode	**Menu > Settings > Call settings > Answer mode**
Time Reminder	**Menu > Settings > Call settings > Time Reminder**
Call Waiting	**Menu > Settings > Call settings > Time Reminder**
Call Forward	**Menu > Settings > Call settings > Call Forward**
Set Display settings	**Menu > Settings > Display settings >** Wallpaper/Screen saver/Show date& time>LCD settings
Shortcuts	**Menu > Settings > Shortcuts**

6.2 Profile Setup

Functions	Description
Activate the profile mode	**Menu > User Profiles >Options > Activate**
Set ring for incoming calls	**Menu > User Profiles > Customize > Tone setup> Incoming**

	calls
Set ring tone for messages	**Menu > User Profiles > Customize > Tone setup> Messages**
Adjust the volume of Ring Tone / Key Tone	**Menu > User Profiles > Customize > Volume**

6.3 Security Settings

Note: To access the 'security settings' folder please enter the default password '0000'

Functions	Description
Phone lock	**Menu > Settings > Security Setup > Phone Lock** The preset password is **0000**
R-UIM lock	**Menu > Settings > Security Setup>CDMA security setup>UIM Lock** **Warning:** If you enter three wrong UIM PIN codes in a row, you need to enter the PUK code to unlock. PIN code and PUK code are provided by the network operator.
Data Password	**Menu > Settings > Security Settings > Password** The default password is '0000'. Enter the password to activate data protection on your phone.
Call Blacklist	**Menu > Settings > Security Setup > Call Blacklist** Allows you to restrict a desired number from calling on your number.
Message Blacklist	**Menu > Settings > Security Settings > Message Blacklist** Allows you to restrict a desired number from messaging on your number.
Storage Erase	**Menu > Settings > Security Settings > Message Blacklist** Allows you to delete all data stored in your phone and UIM memory.
Restore Factory Settings	**Menu > Settings > Security Setup> Restore factory settings**

7 FM Radio

7.1 Fm Radio

Menu > FM Radio

Press Left/Right key to adjust the radio frequency, press Up/Down key to adjust the volume. Press OK key to open or close the radio. Press Right Soft key to background playing, press End key to end it.

Under the open status, press Left Soft key to display the submenus: Save, Channel list, Earphones/Loudspeaker, Manual Input and Auto Search and Save.

Save: Save the current channel. You can save upto 19 channels.

Channel list: Enter the channels list and select someone.

Earphones/Loudspeaker: Activate/deactivate the loudspeaker.

Manual Input: Edit the channel value.

Auto Search and save: Scan automatically.

8 Music Player

8.1 Music Player

Menu > Music Player
Please ensure that the memory card is inserted in your phone before you start to use the music player. You can then access all the songs stored in your memory card and choose to add your favourite songs to create playlists as well.

9 File Manager

9.1 File Manager

Menu>File Manager

9.2 Memory Card

In the idle, select [Menu/File manager/Memory Card] to view the information in the Memory Card and execute the corresponded operations.

9.3 Memory Status

In the idle, select [Menu/File manager/Memory Status] to view the capacity of Memory Card.

10 Alarm

10.1 Alarm

Menu>Alarm

In the idle, select [Menu/Alarm] to edit five alarm clocks. Press the Left Soft key to turn on/off the alarm; Press the OK key to enter the edit interface. Edit the time from the keypad; press Up/Down key to select options; press Left/Right key to select the content of the options. After set completed, press Left Soft key to confirm.

11 Games

11.1 Games

Menu>Games

Your phone provides you with two games – Push box and Tetris. Play the games to cross different levels and make a high score.

12 Organizer

Functions	Description
Memo	**Menu > Organizer > Memo**
Calculator	**Menu > Organizer> Calculator**
View the calendar	**Menu > Organizer > Calendar**
Auto power OFF	**Menu > Organizer > Auto power OFF**
World clock	**Menu > Organizer > World clock**
Stopwatch	**Menu > Organizer > Stopwatch**
Timer	**Menu > Organizer > Timer**
Currency Converter	**Menu >Organizer > Currency Converter** Input the exchange rate and Press **OK**. Select the exchange rate, input the figure and press **OK.**

13 Maintenance

Use a dry soft cloth to wipe general dirt.
Do not use a hard cloth, benzene or thinner to wipe the phone, otherwise, the surface of the phone will be scratched or could even result in the fading of colour.

14 Taking Care of your Device

•Your device is a product of superior design and craftsmanship and should be handled with care: The following suggestions will help you protect your phone:
•Always keep the small parts of the phone away from children.
•Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will rust electronic circuits. If your device does get wet, remove the battery, and allow the device to dry completely before replacing it.
•Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
•Do not store the device in high or cold temperature. High temperatures can shorten the life of electronic devices and damage batteries.
•Do not attempt to open the device other than as instructed in this guide.
•Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
•Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device.
•Do not paint the device. Paint can clog the moving parts and prevent proper operation.
•Use chargers indoors

15 After Services

For details, see the After Service Guide supplied with the phone.